

 RAND McNALLY

FORIS™



Bike Mount Install Guide

ATTACHING THE BIKE MOUNT



1. Push up on the lever at the top of the mount to release the lock.



2. Wrap the strap around the handlebar and reinsert the locking lever.



3. Adjust to fit as necessary by releasing the tab in the middle of the bracket and pulling the strap.



4. Once in place, the mount holds securely to the handlebar.

Note: To mount to the stem, remove the screws, rotate the bracket 90 degrees, and replace the screws.



5. Slide the device into the bracket until it clicks into place.



6. To remove the device, press down on the tab at the bottom of the bracket and slide off.